CDX Diesel HVAC



Module 4: Climate Control

- AIR-CONDITIONING ELECTRONIC CONTROL UNIT (ECU)
- CONTROLLING CABIN AIR TEMPERATURE
- SERVO MOTORS
- ELECTRIC SERVO MOTORS

Air-Conditioning Electronic Control Unit (ECU)

- What is an automatic air conditioner?
 - A manual air conditioner and heating system equipped with sensors that detect changes in:
 - Ambient temperature
 - Cabin temperature
 - Solar radiation
- What does the ECU do?
 - Evaluates the signals from sensors to determine the operating conditions
 - Controls the actuators to move the dampers and valves
 - These control the volume, temperature, and direction of the air delivered by the system.
- Manual mode
 - The climate control system can be operated in manual mode.
 - Operation is similar to the normal heater and airconditioner system.
 - The driver determines:
 - ° Where air is delivered
 - ° The volume of air delivered
 - Air temperature
- Full automatic mode
 - The ECU receives signals from the sensors.
 - Controls the flaps and valves of two systems
 - Creates a blend of air that matches the temperature selected by the occupants
- The ECU's microcomputer
 - The ECU contains a microcomputer.
 - Constructed from a printed circuitry
 - Has a large number of electrical components and electronic devices
 - Normally housed in a metal or plastic container
 - In some systems, the control panel is part of the ECU.

- AUTOMATIC CLIMATE CONTROL SENSORS
 EVAPORATIVE TEMPERATURE SENSOR
 BLOWER SPEED CONTROL
- VENTILATION SYSTEMS
- Signals from the sensors
 - The ECU receives signals in the form of voltages from:
 - Ambient air temperature sensor
 - ° Cabin air temperature sensor
 - ° Coolant temperature sensor
 - ° Evaporator temperature sensor
 - Sun load sensor
 - Control panel
- Comparison of voltage values
 - The ECU compares the voltage values from the sensors with values stored in its memory.
 - If there is a difference in values, the ECU changes the position of the actuators.
- Actuators
 - Electric solenoids and electric motors
 - Control the position of the doors and taps either directly, or by vacuum servos
- Speed of the interior ventilation fan
 - The ECU controls the speed of the interior ventilation fan.
 - The speed of the fan is infinitely variable between a stopped condition and the fan's maximum speed.
- Feedback signal to the ECU
 - Some actuators provide a feedback signal to the ECU.
 - In the form of a voltage signal
 - The signal is used by the ECU to determine:
 - ° Position the actuators are in
 - ° Whether or not the actuators are moving

Controlling Cabin Air Temperature

READY FOR REVIEW

- In automatic mode, the ECU:
 - Uses the last operator desired cabin setting of 75.2°F (24°C)
 - Checks the temperature of the outside air ("ambient air" temperature)
 - Registered by the ambient air temperature sensor at 82.4°F (28°C)
- Parked in bright sunlight
 - Radiation from the sun heats the cabin air temperature to 113°F (45°C).
 - The sun load sensor registers when the vehicle is in bright sunlight.
- The engine starts.
 - When the engine starts and the climate control system is functioning:
 - The ECU switches on the air-conditioning compressor.
 - Increases the speed of the interior ventilation fan
- Air flow
 - Air is drawn into the fan:
 - From outside the vehicle
 - ° From within the cabin

Servo Motors

- The function of servo motors
 - Used to control the flaps and valves in the heater and air-conditioning systems
 - Repositioning of the flaps and valves
 - The output temperatures is adjusted to the temperature desired by the vehicle occupants.
- Types of servo motors
 - Vacuum servos
 - Electrical servos
- Vacuum servo construction
 - The sealed housing is divided by a flexible diaphragm.
 - The diaphragm seals the housing into two separate chambers.
- Two sides of the chambers
 - One side is opened to the atmosphere.
 - The other side is sealed with fitting for the vacuum hose connection.
 - A spring forces the diaphragm towards one side when no vacuum is applied to the diaphragm.
- Diaphragm linkage
 - Linkage from the diaphragm
 - Connects it to the component to be moved

- Flows through the air-conditioning evaporator core
- Heat is removed.
- Cold air-conditioned air
 - Directed by flaps and ducts throughout the cabin of the vehicle
 - Absorbs heat from the vehicle cabin and its occupants
 - Lowers the temperature
- Cabin air temperature
 - Continually measured by the cabin air temperature sensor
 - The temperature lowers to within approximately 35.6°F (2°C) of the desired selection.
 - Fan speed gradually reduces.
- Achieving final control
 - The heater circuit may be opened and the blend door moved.
 - Directs some of the cold air-conditioned air through the heater core
 - Provides fine temperature control
 - Both the fan speed and the blend door openings are variable.
- Supplying the vacuum to the sealed side
 - The vacuum is supplied to the sealed side of the diaphragm.
 - A difference in air pressure occurs across the diaphragm.
 - The force developed overcomes the spring force.
 - The diaphragm moves.
 - The spring is compressed and the linkage is moved.
- Admitting air to the vacuum side
 - Admitting air to the vacuum side of the diaphragm allows the spring to return the diaphragm to a rest position.
- Applying the vacuum for movement, when movement is desired
 - The vacuum is applied to one side of the diaphragm.
 - Atmospheric air pressure is applied to the other side.
- Controlling the vacuum
 - The vacuum delivered to the diaphragm chamber is controlled by the solenoid valve.

- Moving a damper
 - For the ECU to move a damper flap:
 - Grounds the electrical circuit for solenoid winding
 - The vacuum from the storage tank is applied through the solenoid valve to the diaphragm.

Electric Servo Motors

READY FOR REVIEW

- Moving the flaps and valves
 - Movement of the flaps and valves is achieved with electrical motors.
 - Responds to output signals from the ECU
- Moving the blend door
 - The electrical servo motor is used to move the blend door.
 - Incorporates the limit switches
 - Opens the circuit motor when the maximum travel of the door is reached
 - Stops the motor from burning out
- Utilizing a potentiometer
 - Some electrical servos utilize carbon film potentiometers.
 - It signals to the ECU the position of the blend door and if it is moving in the direction in which it is traveling.

Automatic Climate Control Sensors

- ECU and temperatures
 - The ECU needs to know the temperatures of:
 - ° Outside air
 - ° Cabin air
 - Air-conditioning evaporator
 - Coolant circulating through the heater core
 - If the vehicle is in bright sunlight
- Temperature sensors
 - Most temperature sensors used in the climate control air-conditioning system are thermistors.
 - May vary in appearance
 - The general operating characteristics are the same.
- About thermistors
 - Solid state electronic devices
 - Change the resistance in response to the temperature
 - As the temperature of the sensor increases, the resistance decreases.
 - Have a negative temperature coefficient (NTC)
 - Known as NTC resistors

- Releasing the diaphragm
 - The ECU open-circuits the solenoid.
 - The diaphragm returns to a rest position.
- Other diaphragms
 - Some diaphragms use two sealed chambers.
 - Neither end opens directly to the atmosphere.
- Applying voltage
 - Voltage from the ECU is applied across the potentiometer.
 - The wiper is connected by a signal wire to the ECU.
- Achieving maximum cooling
 - The blend door moves to stop the air flow through the heater core.
 - In this position, the voltage signal back to the ECU is at the lowest value.
 - As the blend door moves to allow the air flow through the heater core, the voltage at the signal wire progressively increases.
 - At the maximum heat position, the voltage signal is at its highest.
- Monitoring by the control unit
 - Blend door position
 - Movement
 - Direction of travel
- ECU and sensor voltages
 - When connected into the circuit, the sensor changes the voltage at the ECU.
 - The ECU reads the sensor voltage as a temperature.
 - Compares the reading with information stored in its memory
- Ambient air temperature sensor
 - Measures the temperature of the outside air
 - Usually located in front of the air-conditioning condenser
 - The forward motion of the vehicle and the action of the condenser fans force air over the sensor.
- If the outside air is cold
 - The ambient air temperature sensor resistance is high.
 - The voltage at the ECU is also high.
- If the outside air is hot
 - The ambient air temperature sensor resistance is low.
 - The voltage at the ECU is also low.

CDX Diesel HVAC

- Cabin air temperature sensor
 - Mounted in the tube-type device called the aspirator
 - The one end of the tube is open to the cabin air.
 - The other end is connected to the interior fan.

Evaporative Temperature Sensor READY FOR REVIEW

- Location of the sensor
 - Located in the air stream where the air leaves the evaporator
 - Signals to the control unit the temperature of the air
- Signal sent by the coolant temperature sensor
 - The coolant temperature sensor for the engine management system signals to climate control the ECU temperature of the coolant flowing in the heater core.
 - Some climate control systems have a separate coolant temperature sensor.
 - Usually located near the engine management coolant sensor
- Other sensor signals controlling the heater and fan operation
 - To control heater and fan operation, signal from the coolant temperature sensor used with signals from:
 - Ambient air sensor
 - Sun load sensor
 - ° Cabin air temperature sensor
- The ECU registers readings from the sensors.
 - Example: The ECU registers the following readings: • Coolant temperature: 60.8°F (16°C)
 - Ambient Air temperature: 32°F (0°C)
 - Sun load: 0
 - ° Cabin air temperature: 32°F (0°C)

Blower Speed Control

- The blower motor supplies the air flow to move air around the inside of the passenger compartment.
- The blower motor is located in the ventilation system before the air-conditioning evaporator.
- Manual air-conditioner switch and motor operation
 - The switch connects the resistors in the series with the motor to control its speed.
 - The higher the resistance connected in the series with the motor, the slower the motor operates.
 - Reducing the series resistance increases the motor operating speed.
- Fan motor speeds
 - Most systems use two resistors.

- Operation of the interior fan creates a flow of air through the aspirator.
- The temperature of the cabin air flowing through the aspirator controls a signal sent to the ECU.
- Result of the readings
 - The heater tap opens fully.
 - The blend door moves to maximum air flow across the heater core.
 - The fan speed is slow and steady.
- Sun load sensor
 - Also called a solar sensor
 - Located on the dash panel
 - Exposed to the light entering through the vehicle windscreen
 - The photo diode becomes more conductive as the light intensity increases.
 - When connected to the ECU, the change in light intensity is registered as a change in voltage.
- Operator's control panel
 - Other inputs to the ECU from the operator's control panel are:
 - Where to deliver the air (switches producing an on-off type signal)
 - Instructions regarding the desired cabin temperature
- ECU and desired temperature selection
 - The desired temperature selection tells the ECU what the temperature operator wants for the inside of the vehicle.
 - The ECU adjusts the position of the valves and flaps to achieve the desired temperature.
 - Gives three driver-selectable speeds of the fan motor
 - In climate control systems, the speed of the fan motor is controlled electronically.
 - The control unit modulates the pulse width signal.
 - The longer pulse width produces a higher fan speed.
- ECU and temperature
 - The ECU changes the fan motor speed automatically.
 - The speed depends on the difference between the interior cabin temperature and the set temperature.

- With a large difference in temperature, the fan speed increases.
- Greater air circulation through the cabin
- With a decreased difference in temperature, the fan motor speed decreases.

Ventilation Systems

- Ventilation system function
 - Fitted to vehicles to make the environment in the cabin comfortable for the occupants
 - Ducts:
 - Air to the windshield for defrosting
 - Temperature-controlled air to the foot well and to the face and side vents for occupant comfort
- Air sources
 - From outside the vehicle, usually via apertures located below the windshield
 - Recirculated from within the cabin
- Air movement
 - Air is drawn over the fan and directed over the airconditioning evaporator (if fitted).
 - Moves through the heater core
 - Directed to the desired outlets by ducting and control doors
 - Fresh air normally flows through the cabin when the vehicle is moving.
 - A fan is used to assist air movement.
- Dashboard ventilation switches
 - A set of switches located on the dashboard control:
 - Fresh or recirculated air
 - Mode switch
 - Fan speed switch
 - Air temperature
 - Air-conditioning operation
- Set to fresh air
 - Outside air is drawn from the front of the vehicle.
 - Ducted through the cabin
 - Exhausted to the outside through a flap located in the rear of the passenger compartment
- Air filtering
 - Air pickup may direct air through the filter.
 - Prevents dust, dirt, and pollen from entering the cabin
 - Air is directed to the electric fan.
 - The fan is activated if more airflow is needed.
 - The movement of the vehicle through the air is usually enough to provide adequate airflow.
- Set to recirculate air
 - Closes entry to the outside
 - Opens the duct that directs the cabin air to the fan

- Infinitely variable fan speed between zero and the maximum speed
- Change is progressive.
- No assistance from the vehicle moving through the air
- The fan must be operating to circulate the air.
- Mode switch
 - Controls the outlet or combination of outlets for airflow
 - Air is guided by a series of ducts to the doors.
 - The doors open and close to direct the air to the desired outlet.
 - May have modes to direct the flow:
 - Towards the face or feet
 - To the front or rear of the compartment
 - To other places
- Demisting
 - The mode switch always has a position for windshield defrosting.
 - Directs air onto the inside of the windshield
 - Clears any fogging
- Fan speed switch
 - Controls the electric motor with a barrel-type fan attached
 - Forces air at a chosen speed through the ducting into the passenger compartment via heating and cooling components
- Air temperature (manual)
 - Occupants make selections and adjustments manually.
 - Uses a combination of fan speed and heating or cooling for the preferred comfort level
- Air temperature (automatic)
 - Occupants simply choose the preferred temperature.
 - The control system automatically heats or cools the air.
 - Boosts the fan speed temporarily until the vehicle has reached a target comfort level
 - Maintains in that condition
- Rear passengers
 - Many vehicles separately duct the air through to the rear passengers.
 - Normally, passengers only determine the direction of airflow.
 - Some vehicles are fitted with additional temperature and mode switches.

- Air-conditioning operation
 - All vehicles can direct the air over the heater core to warm the air entering the cabin.
 - Air conditioning is becoming common as a standard fitting in many countries.
 - Still an optional extra on many vehicles
 - When fitted, the air-conditioning evaporator chills the incoming air to cool the occupants if required.
 - Some vehicles automatically activate the air conditioning when the windshield defroster is selected.
 - The air exiting the evaporator is very dry, speeding the defrosting process.

- Driver comfort and safety: air conditioning
 - Highly desirable in warmer climates
 - The interior of the vehicle in direct sunlight heats up very quickly.
 - Safe driving is best performed when the driver is comfortable and not stressed by excessive heat or cold.